

## **Sample Packing Tips**

## **Tube Shipping Preparation**

Tubes should be secured with plastic wrap prior to shipping. This keeps tubes in order and greatly reduces the chance of tubes breaking during transit.



Example of tubes secured in plastic wrap.

Example of unsecured tubes upon their arrival in the lab. Tubes may arrive broken or damaged otherwise.





For questions, contact API Customer Support/Sales: (877) 278-1344 or sales@animalprofiling.com

Headquarters and lab: 6040 N. Cutter Circle, Ste. 317, Portland, OR 97217, (503) 247-8066, www.animalprofiling.com